

# Fuse Carrier

## Fuse Carrier



### Fuse Carrier

Description	P.U.	Cat ref.
Fuse carrier 1P 32A 690V L38 1M	12	<b>LSN501</b>
Fuse carrier 1P 50A L51 acc. 1.5M	1	<b>LS601</b>
Fuse carrier 2P 50A L51 acc. 3M	1	<b>LS602</b>

LSN501

---